



BOTTOM BRACKET SHELL FACING CUTTER

incl. facing cutter
bottom bracket shell diameter: 44mm
code 720007



Application

1. Select the appropriate BB thread insert (BSA L/R, ITAL or FRANC) and guide bushing. Mount the facing tool securely into the bottom bracket shell.
2. Lightly tension the compression spring with the help of the threaded sleeve.
3. Evenly mill the face of the bottom bracket shell until a clean, smooth surface is achieved. Pay attention to the rotation direction of the face milling cutter and always use sufficient cutting oil when milling!
4. Now mount the face milling tool into the bottom bracket shell from the opposite direction and mill the face of the opposite side.

Note: BSA threads have a L/R orientation!

SPARE PAIR

bottom bracket shell facer
code 720027



CUTTING OIL 100 ML
in dispenser bottle
code 710012